

PHARMA DEVILS

Title: Operation of Boiler				
SOP No.:	Revision No.:	00		
Effective Date:	Supersedes No.	Nil		
Review Date:	Page No.	1 of 3		

1.0 OBJECTIVE

To describe a procedure for the Operation of Boiler.

2.0 SCOPE

This procedure applies to the Engineering department.

3.0 RESPONSIBILITY

Engineering

4.0 ACCOUNTABILITY

Plant head

5.0 REFERENCE (S)

In-house

6.0 PROCEDURE

- 6.1 Prestart check are as follows:
 - 6.1.1 Check the soft water level in the feed day tanks.
 - 6.1.2 Check the fuel level in the oil day tank.
 - 6.1.3 Open the valves of steam trap bypass valve.
 - 6.1.4 Open the steam by pass drain valve.
 - 6.1.5 Check the electrical connections.

6.2 Starting the boiler:

- 6.2.1 Open the fuel valve.
- 6.2.2 Inch the pump & check the direction of the reciprocating pump.
- 6.2.3 Set the required steam.
- 6.2.4 Start the boiler.
- 6.2.5 Now fire the boiler by switching ON the ignition push button in the panel.
- 6.2.6 After reaching the pressure of 2 to 2.5 kg / sq.cm in the tank, blow down the boiler.
- 6.2.7 Open the main steam valve.
- 6.2.8 Close the drain steam valve.
- 6.2.9 Check for any leakages for steam & water from valves, pipe joints.
- 6.2.10 Maintain the steam pressure between 7 kg/cm² to 8.0 kg/cm².
- 6.2.11 Check & record the observations as per Format No.

6.3 Shutting down the boiler:

- 6.3.1 Switch off the boiler.
- 6.3.2 Wait till steam pressure reduces to zero.
- 6.3.3 Close the main steam valve.

7.0 HISTORY

Details are given below

SOP No.	REASON FOR CHANGE	EFFECTIVE DATE
	Temp and Pressure limits included in the sop	
	Periodic Review	



PHARMA DEVILS

 Title: Operation of Boiler

 SOP No.:
 Revision No.:
 00

 Effective Date:
 Supersedes No.
 Nil

 Review Date:
 Page No.
 2 of 3

8.0 ABBREVIATIONS: The abbreviations used in the SOP are as follows:

SOP - Standard Operating Procedure

No. - Number

QA - Quality Assurance



PHARMA DEVILS

Title: Operation of Boiler					
SOP No.:	Revision No.:	00			
Effective Date:	Supersedes No.	Nil			
Review Date:	Page No.	3 of 3			

ANNEXURE –I BOILER

WATER METER READING FUEL TANK LEVEL

START MIN
STOP MIN
USED LIT.
START MIN
START MIN
STOP MIN
USED LIT.

DATE: SHIFT:				START TIME:			STOP TIME:		
S.No.	TIME	FUEL			STEAM		BLOW	DONE BY	REMARKS
		TEMP (20-25) °c	PRESSURE (10-12) Kg/cm ²	TEMP (165-170) °C		PRESSURE (7-8) Kg/cm ²	DOWN TIME		

Prepared	by:
----------	-----

Checked by: