

PHARMA DEVILS

ENGINEERING DEPARTMENT

Title: Operation of Diesel Generator Set

SOP No.:	Revision No.:	00
Effective Date:	Supersedes No.	Nil
Review Date:	Page No.	1 of 3

1.0 OBJECTIVE:

To lay down a procedure for Operation of Diesel Generator Set.

2.0 SCOPE:

This SOP is applicable for Operation of Diesel Generator Set.

3.0 RESPONSIBILITY:

Officer / Executive – Engineering

4.0 ACCOUNTABILITY:

Head – Engineering

5.0 ABBREVIATIONS:

ER Engineering

MCCB Moulded Case Circuit Breaker MMI Main Machine Interphase SOP Standard Operating Procedure

6.0 PROCEDURE:

6.1 TO "ON" THE DG SET:

- **6.1.1** Switch 'OFF' the air circuit breaker.
- **6.1.2** Insert the ignition key in MMI & check the status of all parameters.
- **6.1.3** Start the engine in idle mode and run for one minute in idle mode.
- **6.1.4** Check the voltage from the electrical panel.
- **6.1.5** Put the load on alternator step by switching 'ON' MCCB.
- **6.1.6** Monitor the parameters displayed in MMI.

6.2 TO "OFF" THE DG SET:

- **6.2.1** Switch 'OFF' the MCCB.
- **6.2.2** Disconnect the load step by step from alternator.
- **6.2.3** Switch 'OFF' the breaker from changeover panel.
- **6.2.4** Put the engine in idle / cooling mode for 3 minutes.
- **6.2.5** Shut 'OFF' the engine with the help of ignition key.
- **6.2.6** Switch 'ON' the Air circuit breaker



PHARMA DEVILS

ENGINEERING DEPARTMENT

Title: Operation of Diesel Generator Set

SOP No.:	Revision No.:	00						
Effective Date:	Supersedes No.	Nil						
Review Date:	Page No.	2 of 3						

6.3 Record the operation detail in **Annexure** - **I.**

7.0 ANNEXURES:

ANNEXURE No.	TITLE OF ANNEXURE	FORMAT No.			
Annexure-I	Log for Diesel Generator Set				

ENCLOSURES: SOP Training Record

8.0 DISTRIBUTION:

• Controlled Copy No. 01 Quality Assurance

• Controlled Copy No. 02 Engineering

• Master Copy Quality Assurance

9.0 REFERENCES:

Manual of DG Set.

10.0 REVISION HISTORY

CHANGE HISTORY LOG

Revision	Change	Details of Changes	Reason for Change	Effective	Updated
No.	Control No.			Date	By



PHARMA DEVILS

ENGINEERING DEPARTMENT

Title: Operation of Diesel Generator Set							
SOP No.:	Revision No.:	00					
Effective Date:	Supersedes No.	Nil					
Review Date:	Page No.	3 of 3					

ANNEXURE – I LOG FOR DIESEL GENERATOR SET

Diesel Generator No.:

Date	Start time	Stop time	Reading Time	RPM	Oil Pressure	Coolant Temp.	Meter Start (Hr.)	Meter Stop (Hr.)	Battery Voltage	Amp.	Frequency	Operator Sign.	Checked By