

PHARMA DEVILS

ENGINEERING DEPARTMENT

STANDARD OPERATING PROCEDURE		
Department: Engineering	SOP No.:	
Title: Operation of Wet Scrubber	Effective Date:	
Supersedes: Nil	Review Date:	
Issue Date:	Page No.:	

1.0 REVISION HISTORY

Rev. No.	Details of changes	Reason for change
00	NIL	NEW SOP

2.0 OBJECTIVE

The objective of this SOP is:

- **2.1** To describe the procedure for operation of Wet Scrubber.
- **2.2** To monitor the performance of the Wet Scrubber.

3.0 SCOPE

3.1 This SOP is applicable for the operation of Wet Scrubber at Alkem Health Science, Samardung, South Sikkim.

4.0 RESPONSIBILITY

- **4.1** The Plant Operator shall be responsible for:
 - **4.1.1** The operation of Wet Scrubber.
 - **4.1.2** Monitoring the operation.
 - **4.1.3** Reporting for abnormal behavior.
- **4.2** The Engineer shall be responsible for:
 - **4.2.1** Corrective action in case of any deviation.
 - **4.2.2** Verifying the performance parameters as per acceptance criteria.



PHARMA DEVILS

ENGINEERING DEPARTMENT

STANDARD OPERATING PROCEDURE		
Department:	SOP No.:	
Title: Operation of Wet Scrubber	Effective Date:	
Supersedes: Nil	Review Date:	
Issue Date:	Page No.:	

5.0 ACCOUNTABILITY

Head - Engineering Services.

6.0 PROCEDURE:

6.1 PRIMARY CHECKS:

- **6.1.1** Open the water inlet valve to the Wet Scrubber.
- **6.1.2** Ensure that the incoming dampers of all connected duct are open.

6.2 STARTING PROCEDURE:

- **6.2.1** Switch 'On' the water circulation pump.
- **6.2.2** After 2 -5 minutes and switch 'On' the exhaust air blower of Wet Scrubber.
- **6.2.3** Operator concerned should give blow down for 5-10 minutes to reduce the Concentration of dust in the sump of wet scrubber. Blow down should be given once in a day.

6.3 STOPPING PROCEDURE:

- **6.3.1** Switch 'Off' the exhaust air blower.
- **6.3.2** Let the pump run 5-10 minutes and switch 'Off' the pump.

7.0 ANNEXURES:

NIL.

8.0 REFERENCES (S)

NIL.

9.0 GLOSSARY

SOP : Standard Operating procedure

No : Number