



PHARMA DEVILS

ENGINEERING DEPARTMENT

STANDARD OPERATING PROCEDURE

Department: Engineering	SOP No.:
Title: Checking the Earth Continuity	Effective Date:
Supersedes: Nil	Review Date:
Issue Date:	Page No.:

1.0 REVISION HISTORY

Rev. No.	Details of changes	Reason for change
00	NIL	NEW SOP

2.0 OBJECTIVE:

2.1 The Objective of this SOP is to describe the procedure for checking the Earthing continuity.

3.0 SCOPE:

3.1 This SOP is describing the procedure for checking the Earthing continuity.

4.0 RESPONSIBILITY:

4.1 The Maintenance Engineer shall be:

4.1.1 Responsible for checking the Earthing continuity.

4.1.2 Responsible for the corrective action in case of any deviation

5.0 ACCOUNTABILITY:

Head –Engineering Services

6.0 PROCEDURE:

6.1 Take a multi-meter and set the selector switch in 'Continuity' mode.

6.2 Take two testing cords and connect the one end of each cord with multi-meter.

6.3 Connect the other ends of each cord between the equipment and main Earthing strip/wire.

6.4 If display is showing zero on the millimeter and a audio is heard then earthing continuity Satisfactory.



PHARMA DEVILS

ENGINEERING DEPARTMENT

STANDARD OPERATING PROCEDURE

Department: Engineering	SOP No.:
Title: Checking the Earth Continuity	Effective Date:
Supersedes: Nil	Review Date:
Issue Date:	Page No.:

7.0 ANNEXURE:

NIL

8.0 REFERENCES (S)

Nil

9.0 GLOSSARY

SOP : Standard Operating procedure

No : Number