

PHARMA DEVILS

ENGINEERING DEPARTMENT

TITLE: Operation of BoilerSOP No.:Revision No.:00Effective Date:Supersedes No.NilReview Date:Page No.1 of 4

1.0 OBJECTIVE:

To lay down a procedure for Operation of Boiler.

2.0 SCOPE:

This SOP is applicable for Operation of Boiler at

3.0 RESPONSIBILITY:

 $Officer\ /\ Executive\ -\ Engineering$

4.0 ACCOUNTABILITY:

Head-Engineering

5.0 **DEFINITION:**

Not Applicable

6.0 **PROCEDURE**:

6.1 PRE STARTUP CHECKS:

- **6.1.1** Check the Furnace Oil Level in service tank.
- 6.1.2 Check the water level in service tank.
- **6.1.3** Close the boiler main steam valve.
- 6.1.4 Check the furnace oil temperature, it shall not less than 50 degree Celsius.

6.2 START OPERATION:

- **6.2.1** Switch "**ON**" the Main Control Panel Power Supply.
- 6.2.2 Put the selector switch in Auto Mode.
- **6.2.3** Start the Boiler by pressing the START button Control Panel.
- **6.2.4** Check the force draft blower gets ON.
- 6.2.5 Boiler firing shall start after few minute after force draft blower gets on.
- **6.2.6** Observe the increasing pressure, once it reach to 7 Kg/Cm², open the steam valve.



ENGINEERING DEPARTMENT

TITLE: Operation of Boiler

SOP No.:	Revis	ion No.:	00
Effective Date:	Super	rsedes No.	Nil
Review Date:	Page	No.	2 of 4

- **6.2.7** Check for unusual noises.
- **6.2.8** Check for loose Nuts and bolts if any & rectify/tight the same.

6.3 STOP OPERATION:

- **6.3.1** Switch OFF button (O) from control panel, the Boiler shall stop.
- 6.4 Record the Operation Details of Air Compressor in "Boiler Operation Record" as shown in Annexure-I.

7.0 ABBREVIATIONS:

SOP	Standard Operating Procedure
No.	Number
Ltd.	Limited
QA	Quality Assurance
Kg	Kilogram
cm	Centimeter
PLC	Programmable Logic Controller

8.0 ANNEXURES:

ANNEXURE No.	TITLE OF ANNEXURE	FORMAT No.
Annexure-I	Boiler Operation Record	

9.0 **DISTRIBUTION:**

- Controlled Copy No. 1 Head Engineering
- Master Copy
 Quality Assurance Department

10.0 REFERENCES:

Not Applicable



PHARMA DEVILS

ENGINEERING DEPARTMENT

TITLE: Operation of Boiler				
SOP No.:	Revision No.:	00		
Effective Date:	Supersedes No.	Nil		
Review Date:	Page No.	3 of 4		

11.0 REVISION HISTORY:

Revision No.	Change Control No.	Details of Changes	Reason of Changes	Effective Date	Done By
00	Not Applicable	Not Applicable	New SOP		



PHARMA DEVILS

ENGINEERING DEPARTMENT

TITL	E: Op	eration of	f Boiler					
SOP N			Revision No.: 00					
Effect	tive Da	te:	Supersedes No. Nil					
Revie	w Date	e:	Page No.4 of 4					
	ANNEXURE – I							
			PHARMA DEVILS ENGINEERING DEPARTMENT					
					ENGINE	ERING DEPA	RTMENT	
						PERATION F		
Block	•			L	ocation:		ID No	•••
Dete	Date Time	ime Running Hrs.	Boiler Outle	et	FO Level	Operator Sign &	Checked	Remarks
Date			Pressure	Temperature				
Limit→			(6-7Kg/cm ²)	(25 – 50°C)	10 2000	Date	By Sign & Date	