

PHARMA DEVILS

Title: Preventive Maintenance of Lifter and Positioner				
SOP No.:	Revision No.:	00		
Effective Date:	Supersedes No.	Nil		
Review Date:	Page No.	1 of 3		

1.0 OBJECTIVE

1.1 To describe a procedure for the preventive maintenance of lifter and positioner.

2.0 SCOPE

2.1 This procedure applies to the Engineering department.

3.0 **RESPONSIBILITY**

3.1 Engineering

4.0 ACCOUNTABILITY

4.1 Plant Head

5.0 **REFERENCE** (S)

5.1 In-house.

6.0 **PROCEDURE**

- 6.1 Procedure for mechanical work:
 - 6.1.1 Switch off the machine and put "under maintenance" label.
 - 6.1.2 Clean the hydraulic tank from outside and tighten the connecting ferrule.
 - 6.1.3 Check the level of the Hydraulic oil in the tank if it is less than half, make up by servo 220 grade oil.
 - 6.1.4 Clean the side plates and cover plates.
- 6.2 Procedure for electrical work:
 - 6.2.1 Clean the technical floor panel board by handy blower.
 - 6.2.2 Clean the contactor and tighten the wire connection.
 - 6.2.3 Check the NO/NC element of UP/DOWN movement.
 - 6.2.4 Check the operation of limit switch.
- 6.3 Procedure for trial run:
 - 6.3.1 Switch on the power supply.
 - 6.3.2 Check for the smooth operation of the lifter referring the SOP.
 - 6.3.6 Check & record the observations as per Annexure-1.
- 6.4 Procedure for handover of the machines:
 - 6.4.1 Remove "under maintenance" label & affix preventive maintenance status tag and inform the concerned department.
- 6.5 Frequency of preventive maintenance is once in two months.

7.0 HISTORY



PHARMA DEVILS ENGINEERING DEPARTMENT

Title: Preventive Maintenance of Lifter and PositionerSOP No.:Revision No.:00Effective Date:Supersedes No.NilReview Date:Page No.2 of 3

7.1 Details are given below.

SOP No.	REASON FOR CHANGE	EFFECTIVE DATE

8.0 ABBREVIATIONS: The abbreviations used in the SOP are as follows:

- 8.1 SOP Standard Operating Procedure
- 8.2 No. Number
- 8.3 QA Quality Assurance



PHARMA DEVILS ENGINEERING DEPARTMENT

Title: Preventive Maintenance of Lifter and PositionerSOP No.:Revision No.:00Effective Date:Supersedes No.NilReview Date:Page No.3 of 3

ANNEXURE-I

PREVENTIVE MAINTENANCE CHECK LIST FOR LIFTER & POSITIONER

Equipment ID No._____

Date: _____

S.No.	Particulars	Done/Not Done	Remarks
1	Cleaning of the machine.		
2	Checking of operative units.		
3	Check pneumatic controls, solenoid valve.		
4	Checking electrical connections.		
5	Checking of wire rope & pulley alignment.		
6	Oil level in power pack.		

Done by (Sign & date) Checked by (Sign & date)