

PHARMA DEVILS ENGINEERING DEPARTMENT

Title: Preventive Maintenance of Shipper Packing machine			
SOP No.:		Revision No.:	00
Effective Date:		Supersedes No.	Nil
Review Date:		Page No.	1 of 3

1.0 OBJECTIVE

1.1 To describe a procedure for the preventive maintenance of shipper packing machine ITW-SIGNOD (model-4AM).

2.0 SCOPE

2.1 This procedure applies to the Engineering department.

3.0 **RESPONSIBILITY**

3.1 Engineering

4.0 ACCOUNTABILITY

4.1 Plant Head

5.0 **REFERENCE** (S)

5.1 In-house.

6.0 **PROCEDURE**

- 6.1 Procedure for mechanical work:
 - 6.1.1 Switch off the power supply to the machine and put "under maintenance" label.
 - 6.1.2 Check the roller arm assembly.
 - 6.1.3 Check alignment for rollers.
 - 6.1.4 Check the spring tension.
 - 6.1.5 Check the height-adjusting knob.
 - 6.1.6 Check grease in the rollers.
- 6.2 Procedure for electrical work:
 - 6.2.1 Check and tighten all the electrical connections.
 - 6.2.2 Check the proper earthing.
- 6.3 Procedure for trial run:
 - 6.3.1 Switch on the main power supply.
 - 6.3.2 Start the machine as per the SOP.
 - 6.3.3 Check & record the observations as per Annexure-I.
 - 6.3.4 Remove under maintenance label & affix Preventive maintenance status label and inform the concerned department.
- 6.4 Frequency of preventive maintenance is monthly.

7.0 HISTORY

7.1 Details are given below.

SOP No.	SOP No. REASON FOR CHANGE	



PHARMA DEVILS ENGINEERING DEPARTMENT

Title: Preventive Maintenance of Shipper Packing machine

SOP No.:	R	evision No.:	00
Effective Date:	St	upersedes No.	Nil
Review Date:	Pa	age No.	2 of 3

8.0 ABBREVIATIONS: The abbreviations used in the SOP are:

8.1	SOP	- Standard Operating Procedure
-----	-----	--------------------------------

- 8.2 No. Number
- 8.3 QA Quality Assurance



PHARMA DEVILS ENGINEERING DEPARTMENT

Title: Preventive Maintenance of Shipper Packing machine

SOP No.:	Revision No.:	00
Effective Date:	Supersedes No.	Nil
Review Date:	Page No.	3 of 3

ANNEXURE-I

PREVENTIVE MAINTENANCE CHECK LIST FOR SHIPPER PACKING MACHINE MODEL 4AM

Equipment ID No._____

Date: _____

S.No.	Particulars	Done/Not Done	Remarks
1	Check roller arm assembly.		
2	Check alignment for rollers.		
3	Check all electrical connections.		
4	Check the height adjustment knob.		
5	Others.		

Done by (Sign & date) Checked by (Sign & date)