

# PHARMA DEVILS ENGINEERING DEPARTMENT

Title: Preventive Maintenance of Split Air Conditioner			
SOP No.:	Revision No.:	00	
Effective Date:	Supersedes No.	Nil	
Review Date:	Page No.	1 of 3	

## 1.0 OBJECTIVE

1.1 To describe a procedure for the preventive maintenance of split air conditioner.

# 2.0 SCOPE

2.1 This procedure applies to the Engineering department.

# 3.0 **RESPONSIBILITY**

3.1 Engineering

# 4.0 ACCOUNTABILITY

4.1 Plant Head.

# 5.0 **REFERENCE** (S)

5.1 In-house.

#### 6.0 **PROCEDURE**

- 6.1 Procedure for mechanical work:
  - 6.1.1 Switch off the machine and put "under maintenance" label.
  - 6.1.2 Check the gas leakage in cooling coil & copper piping.
  - 6.1.3 Clean the suction filter.
  - 6.1.4 Cleaning of indoor & outdoor units by using compressed air.
  - 6.1.5 Check the compressor & cooling coil.
- 6.2 Procedure for electrical work:
  - 6.3.1 Check the fan motor for its running and vibration.
  - 6.3.2 Check the thermostat & electrical connections.
- 6.3 Procedure of trial run:
  - 6.3.1 Switch on the power supply.
  - 6.3.2 Check & record the observations as per Annexure-I.
- 6.4 Procedure for handover of the machine.
  - 6.4.1 Remove under maintenance label & affix preventive maintenance status tag and inform the concerned department.
- 6.5 Frequency of preventive maintenance is monthly.

#### 7.0 HISTORY

SOP No.	REASON FOR CHANGE	EFFECTIVE DATE

**8.0 ABBREVIATIONS**: The abbreviations used in the SOP are:



# PHARMA DEVILS ENGINEERING DEPARTMENT

Title: Preventive Maintenance of Split Air Conditioner

SOP No.:	Revision No.:	00
Effective Date:	Supersedes No.	Nil
Review Date:	Page No.	2 of 3

8.1 SOP - Standard Operating Procedure

8.2 No. - Number

8.3 QA - Quality Assurance



# PHARMA DEVILS

ENGINEERING DEPARTMENT

Title: Preventive Maintenance of Split Air Conditioner

SOP No.:	<b>Revision No.:</b>	00
Effective Date:	Supersedes No.	Nil
Review Date:	Page No.	3 of 3

## **ANNEXURE-I**

# PREVENTIVE MAINTENANCE CHECK LIST FOR SPLIT AIR CONDITIONER

Equipment ID No.\_\_\_\_\_

Date: \_\_\_\_\_

S.No.	Particulars	Done/Not Done	Remarks
1	Cleaning of indoor & outdoor		
	units by compressed air.		
2	Clean suction filters.		
3	Checking of electrical		
	connections.		
4	Checking of thermostat for		
	temperature controlling.		
5	Checking of cooling coil.		

Done by (Sign & date)

Checked by (Sign & date)